






















Lista części NG-LF

Poz.	Opis		NG-LF				
			10 Nr art.	20 Nr art.	30 Nr art.	50 Nr art.	75 Nr art.
1	Głowica palnika		3-00353	3-00353	3-00353	3-00353	3-00346
2	Detektor płomienia zapłonowego na podczerwień IRD 1020 alternatywny. KLC 2002		100217 1-03090	100217 1-03090	100217 1-03090	100217 1-03090	100217 1-03090
3	Kabel czujnika dla IRD 1020		100720	100720	100720	100720	100720
4	Zestaw gazowy		100912	100911	102873	102873	102873
5	Przełącznik		100867	100867	100925	100925	100925
6	Kondensator		-----	102683	101377	101377	-----
7	Uchwyt magnetyczny dla IRD		100719	100719	100719	100719	100719
8	Zabezpieczający ogranicznik temperatury 230 V		100219	100219	100219	100219	100219
9	Automat kontroli palnika DKG 972 N		1-03419	1-03419	1-03419	1-03419	1-03419
10	Wentylator		102391	102392	102390	102390	100050
11	Łopatką wentylatora		-----	-----	-----	-----	101883
12	Elektroda zapłonu / skrownik		103311	103311	103311	103311	103311
13	Kabel zapłonu		101190	101190	101190	101190	101190
14	Transf. zapłonowy ZAG-1 / Cewka W.N.		101265	101265	101265	101265	101265
15	Zabezpieczenia zerwania węża		102168	103575	102170	102170	102170
16	Regulator ciśnienia gazu		103776	100913	102964	102964	102964
17	Przewód gazowy		1-02441	1-02441	1-02442	1-02442	1-02442
18	Przełącznik		1-00676	1-00676	1-00676	1-00676	1-00676
19	Obudowa skrzynki sterowniczej		1-00946	1-00946	1-01747	1-01747	1-01747
20	Kondensator do usuwania ładunków elektrostatycznych		1-00394	1-00394	1-00394	1-00394	1-00394
21	Podwójny zawór elektromagnetyczny		102693	102693	102693	102693	102693
22	Rura ochronna dla IRD 1020		300289	300289	300289	300289	300289
23	Płyta wirowa / Strumieniowa		300373	300373	300384	300384	300384
24	Bezpiecznik		1-00562	1-00562	1-00562	1-00562	1-00562
25	Przycisk odblokowujący		1-01047	1-01047	1-01047	1-01047	1-01047